




Disposable Cassette

Assembly & User Instructions

1/ Lay flat & check fold lines and cutouts



2/ Squeeze into Lozenge shape and fold in & out along cut & fold lines, Then Square up the box sides.





3/ Fold in the Handle 'Ears' and lock Handle.



4/ Turn G2Go around and Fold the panels as per the picture



5/ Tip box upside down and fold in 'Locking Tab'



6/ Turn box over and check assembly is 'locked'.



7/ Place the Composting Bag Into the G2Go Box and fix with the 'Star- Grips'.



8/ Your "Good2Go Cassette" is now ready to replace your original cassette.



Preparing the Toilet for use

After a thorough clean and refresh you are **Good2Go**. With the Composting Bag insertion, firstly drop a Bag into the Toilet bowl, with a small amount (100ml) or $\frac{1}{2}$ teacup of Cat Litter/ Sawdust etc. Then, fold around bowl, (With Seat Lifted) & Lower the seat, to hold the bag in place.

The **Good2Go** will hold around 4 'used' bags before disposal, and these are the recommended ways to dispose of the contents.



Dealing with waste!!!

The preferred method of dealing with the contents from a 'Compost toilet' is **always** to compost them in a compost bin, as they 'close the loop' and return valuable nutrients safely to the earth.

However, there may be situations, such as in motor homes or Caravans, where it's impossible to compost.

In these situations, you may dispose of small amounts, up to 7kg in municipal waste bins or official council waste disposal sites. (This waste is classed as non-recyclable and is typically used in an energy recovery process)& provided the contents are double-bagged. The contents are referred to as 'offensive waste' and come under the same waste classification as used nappies, adult incontinence pads & colostomy bags

Whatever method you choose,
always dispose of solid waste
safely and responsibly & now
your



Happy Camping

Current models for
THETFORD C2,C3&C4.
& Later Swivel Bowl Models